



Vernier Spreader Adjustment

Assembly of the Spreader to the Mast Spreader Bracket.

1. Use 3mm screw & nut through forward hole No. 1
2. Use 4mm screw & nut through the most forward hole as shown.
3. Do not use hole No.'s 2, 3 or 4
4. The length adjuster can be found attached to the shrouds.
5. At the outboard end of the spreader push the length adjuster into the slot in the end of the spreader.
6. Push the clevis pin through the spreader locating the length adjuster plate as shown & secure with the clevis ring.
7. Please make sure that the holes used for assembly match those shown in the illustration.
8. All clevis pins, rings, nuts & screws must be covered with self amalgamating tape (electrical or PVC tape is best). This will reduce chafing on the mainsail and avoid damage.

